


STC 46 3-Sided Single Frame (Double Rabbet Only)

| FRAME PART | DIMENSIONS |
|--|------------|
| THROAT | |
| MINIMUM | 3 5/16" |
| MAXIMUM | 13" |
| A=Jamb Depth | |
| MINIMUM | 4 5/16" |
| MAXIMUM | 14" |
| D=FACES | |
| MINIMUM | 1 1/4" |
| MAXIMUM | 4" |
| E=RETURNS | |
| MINIMUM | 7/16" |
| MAXIMUM | 3/4" |
| HEIGHT | |
| MINIMUM | 80" |
| MAXIMUM | 96" |
| WIDTH - SGL. | |
| MINIMUM | 24" |
| MAXIMUM | 48" |
| All Hardware Preps receive Mortar Guards | |
| All Frames 14 Ga (CRS & A60 Available) | |
| Butt or Continuous Hinges | |
| ASA, Deadlock, and / or Rim Panic Rein. | |
| Frames Tested without Closer reinf. | |

Available Continuously Welded Only

Rough Opening = Overall Frame Size + Clearance

Non Fire Rated Only



ANCHOR OPTIONS

Masonry & Stud Type (Grout-Filled Only)

All Frames Must be Grouted Solid

STC 46 Single - Sound Rated Door

Proprietary Core

Threshold and All Seals Provided

14 Ga. Continuous (Full Height)
Hinge & Lock Channel Rein.

14 Ga. Top & Bottom Channels
with 16 gauge flush caps

14 Gauge Face Sheets

Non Fire Rated Only

Minimum Size 2-0 x 6-8

Maximum Size 4-0 x 8-0

Continuous or Butt Hinges
Approved (Furnished by Others)

161 or 86 Mortise Lock or Rim
Panic Device Approved (Furnished
By Others)


Thickness 1 3/4"

Beveled or Square Edge Construction

Welded Seamless Construction

Baked On Grey Primer

Hardware Rein: Hinge = 7 Ga.
161 Lock = 16 Ga





STC 46 Single Opening

1-3/4" Thick Flush Single Door and Frame Package

(Available 2068 to 4080 leaf size)

14 gauge "Double Rabbet" continuously welded mortar filled frame

(Frame By HMF – Mortar filled on jobsite)

14 gauge flush door with 3/8" UC (with Proprietary Core) **(By HMF)**

Hardware:

(1) Hager 780-224HD Continuous Hinges (TESTED) **(By Others)**

***4-1/2" or 5" Butt Hinges Approved**

*(1 or 2) Cylindrical Lock(s) 2-3/4" BS x 4-7/8" ASA Strike **(By Others)***

*And / Or (1) Mortise Lock 2 3/4" BS x 4 7/8" ASA Strike **(By Others)***

*And / Or (1) Rim Panic Device with Trim **(By Others)***

(Can have 2 lock preps or 1 lock and 1 panic prep if 2nd lock at typical DL location)

(1) Set Zero 770A at Head and Jambs **(By HMF)**

(1) Zero 367 Auto Door Bottoms **(By HMF)**

(1) Zero 566A Threshold – Size equal to door width **(By HMF)**

(1) Zero 119W Spring Bronze at Head **(By HMF)**

Add (2) 119W at hinge jambs if butt hinges are used **(By HMF)*



STC 46 Sound Seal Package

Zero 770 around perimeter of opening at head and jambs. Seal mounts on top of soffit. Install 564 threshold before the 770 sound seal.

Zero 119W around perimeter of opening at head and jambs. Install in door rabbet just off the stop but not butted up against the stop. This will typically be the last item installed. **Omit 119W at hinge jambs if continuous hinges are used.**


Zero 566 threshold positioned where door bottom seal makes an air tight seal at bottom of door. Threshold should be installed 1st.

Zero 367 automatic door bottom positioned at bottom of door and between 770 seal. Bottom seal should seal on top of 564 threshold.

***** Any vertically latching or locking of doors must be fit so doors have minimal play or movement. Install latching and locking devices for fit before installing perimeter seals and making final adjustments.**



STC 46 – Seals Installation Guide



FIRE RATING



UL listed



10B Classified up to 45 minutes



10C Classified




Category G Listed up to 20 minutes

SMOKE PERFORMANCE



The rubber seal in this gasket provides protection from smoke infiltration in accordance with provisions of NFPA 101 Life Safety Code and NFPA 80 Standard for Fire Doors and Other Opening Protectives



ANSI/BHMA

Legend:

AA = Clear Anodized
D = Dark Bronze Anodized

Head & Jamb

#770AA / 770D

R3B264
R3B204



415 Concord Avenue
Bronx, NY 10455

email: zero@zerointernational.com
web site: www.zerointernational.com

tel: 718.585.3230
fax: 718.292.2243

Part No:

770

Notes:

Part Description:

Adjustable Sealing System
- STC Rated


Provided By:

Customer Name:



Job No:

Date:

#770 Head and Jamb Protection INSTALLATION INSTRUCTIONS



- 1 Close the door and measure the frame opening.
- 2 Install the gasketing (trim as necessary), head piece first. Place the piece against the face of door, making gentle contact between the rubber extrusion seal and the door. Fasten in place.
- 3 Place hinge side piece against the face of door, making gentle contact between the rubber extrusion seal and the door. Fasten in place. Repeat the same procedure with the lock side.
- 4 It is recommended that this gasketing product be set in a bead of caulking to ensure the integrity of the seal and prevent additional sound transmission.
- 5 Adjust the #770 with the adjustment screws as necessary for the desired seal and operation of the door.



ZERO INTERNATIONAL, INC.


415 Concord Avenue, Bronx, NY 10455-1004
 Tel : 718-585-3230 • Fax : 718-292-2243
 E-mail : zero@zerointernational.com
 www.zerointernational.com


FIRE RATING

 UL listed

 10C Classified

SMOKE PERFORMANCE

 The rubber seal in this gasket provides protection from smoke infiltration in accordance with provisions of NFPA 101 Life Safety Code and NFPA 80 Standard for Fire Doors and Other Opening Protectives



Legend:

AA = Clear Anodized
D = Dark Bronze Anodized
G = Gold Anodized

ANSI/BHMA

#367AA / 367D / 367G

R3B334

| | | | |
|--|---|--|---------------------|
|  | <p>415 Concord Avenue tel: 718.585.3230 Bronx, NY 10455 fax: 718.292.2243 email: zero@zerointernational.com web site: www.zerointernational.com</p> | <p>Part No: 367</p> | |
| <p>Notes:</p> | | <p>Part Description: Automatic Door Bottom - High Sound - Surface Mounted / Heavy Duty</p> | |
| <p>Provided By:</p> | <p>Customer Name:</p> | <p>Job No:</p> | <p>Date:</p> |


INSTALLATION INSTRUCTIONS

Automatic Door Bottoms #320, 350, 351, 352, 360, 361, 362, 364, 365, 366, 367, 368, 369








ZERO INTERNATIONAL, INC.
415 Concord Avenue, Bronx, NY 10455-4801
Tel: 718-585-3230 • Fax: 718-292-2243
www.zerointernational.com









Typical Mounting of Automatic Door Bottoms










● Surface-Mounted



● Semi-Mortised




● Mortised



How To Install:

- 1 All surface and semi-mortised units must be mounted on the push side of the door stop (side where the door stop is).
- 2 The brass adjusting nut must be on the hinge side and should not be adjusted until the unit has been mounted.
- 3 Leave 1/16" (1.6) clearance on each end.
- 4 Optimum clearance between door bottom unit and floor or sill is 3/8" (9.5).

TRIMMING INSTRUCTIONS



IMPORTANT!

Push insert as far as possible to the opposite end of the housing from the adjusting nut, before cutting.

FINAL ADJUSTMENT

After unit has been mounted, turn adjusting nut in / out until closing door pushes neoprene seal down to make contact with floor/sill.

FIRE RATING


ITS Warnock Hersey listed



10C Classified

SMOKE PERFORMANCE

The rubber seal in this gasket provides protection from smoke infiltration in accordance with provisions of NFPA 101 Life Safety Code and NFPA 80 Standard for Fire Doors and Other Opening Protectives

**Legend:**

A = Aluminum
B = Bronze
E = Epoxy

ANSI/BHMA

| | |
|--------|-----------------|
| #566A | J36100 / J36130 |
| #566AE | J36200 / J36230 |
| #566B | J16100 / J16130 |
| #566BE | J16200 / J16230 |



415 Concord Avenue tel: 718.585.3230
Bronx, NY 10455 fax: 718.292.2243
email: zero@zerointernational.com
web site: www.zerointernational.com

Part No:

566

Notes:**Part Description:**

Rabbeted Threshold

Provided By:**Customer Name:****Job No:****Date:**

Thresholds

INSTALLATION INSTRUCTIONS

- 1 Measure and cut threshold to size as required.
- 2 Notch as necessary, to suit door frame.
- 3 Caulk underneath and around edges of threshold for moisture control.
- 4 Attach threshold to floor surface with screws provided.




ZERO INTERNATIONAL, INC.

415 Concord Avenue, Bronx, NY 10455-1004

Tel : 718-585-3230 • Fax : 718-292-2243

E-mail : zero@zerointernational.com

www.zerointernational.com



#119WB
#119WS

34 B. & S. Gauge Spring Bronze

Legend:

B = Bronze
S = Stainless Steel

ANSI/BHMA

#119WB
#119WS

R1K155
R5K155



415 Concord Avenue tel: 718.585.3230
Bronx, NY 10455 fax: 718.292.2243
email: zero@zerointernational.com
web site: www.zerointernational.com

Part No:
119W

Notes:

Part Description:

Door Seal

- Adhesive



Provided By:

Customer Name:

Job No:

Date:

#119B / 119WB / 119WS Bronze Cushion Spring INSTALLATION INSTRUCTIONS




Before Installation :

- 1 Thoroughly clean the surface of the frame where gasketing is to be applied (see drawings). Use either a solvent cleaner (such as mineral spirit) or a common detergent cleaner. Make sure to check for any impediments (dust, dirt, oil, grease, loose paint, etc.) and remove them from the surface area.
- 2 Allow surface area to dry COMPLETELY before beginning installation.
- 3 Recommendation: Finish-paint doors and frames and allow the paint to dry before installing the gasketing.

How To Install :

- 1 Install the head piece first along the entire length of the head. Measure and cut the gasketing to size and place properly, referring to drawings for location on the head. Remove the paper backing from the self-adhesive strip (PSA), align on the head and press firmly into place.
- 2 Install the strike jamb gasketing next, following procedures as outlined in step 1. (Refer to drawing for placement on the strike jamb.)
- 3 Install the hinge jamb gasketing last, following procedures as outlined in step 1. (Refer to drawing for placement on the hinge jamb.)



ZERO INTERNATIONAL, INC.

415 Concord Avenue, Bronx, NY 10455-1004
Tel : 718-585-3230 • Fax : 718-292-2243
E-mail : zero@zerointernational.com
www.zerointernational.com